


EN Sun and dusk sensor 3711

Instruction manual

Item no.

7000 00 88 / -89 / -90 / -91 / -92



A light guide measures both the incidental rays of sunlight and the dusk state in the evening. During periods of intense sunshine, the roller shutter lowers as far as the sensor. With the dusk function, the command is given to lower the roller shutter when dusk falls. The values for the desired solar or dusk state can be changed by means of the adjustment screws and with the aid of the corresponding symbols on the device.

Connection:

Via the corresponding connector on the device. The sensor can be affixed to any place on the window. (For details on the connection and function, please also refer to the operating manual for the respective device).

Removing the sensor from the window:

DO NOT PULL ON THE CABLE.

You can pull on the lug to remove the sensor from the window.

DELTA DORE RADEMACHER GmbH

Buschkamp 7

46414 Rhede (Germany)